MPEG4 STAND-ALONE DVR KPD-M Series



User's Manual

- Some system menu can be different from each model
- Some system menu is subject to change by firmware upgrade
- Please read this manual carefully before running DVR system



TO REDUCE THE RISK OF ELECTRICAL SHOCK, DO NOT OPEN COVERS.
NO USER SERVICEABLE PARTS INSIDE. REFER SERVICING TO QUALIFIED SERVICE PERSONNEL.

Please beware of the following precautions before installing the DVR.

Avoid any place with moisture, dust, or soot.

Avoid any place with direct sunlight or heating appliances.

Keep the product away from electric shock or magnetic substances.

Avoid high or low temperature.

(Recommended operation temperature is between 0°C ~ 40°C).

Do not place any conductive material through the ventilation.

Turn off the system before installation.

Ensure enough space for cable connections.

Place the system on a solid surface with sufficient air ventilation.

Avoid any surface that vibrates.

Placing the system near electronic devices such as radio or TV may cause breakdown to the product.

Do not disassemble the product without assistance from the manufacturer.

Do not place any heavy object on the system.

NOTE

This equipment had been tested and found to comply with the limits for a CLASS A digital device, pursuant to Part 15 of FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment.

PLEASE READ THIS MANUAL THOROUGHLY FOR EFFECTIVE AND SAFE USAGE OF THE DEVICE.

CONTENTS

I. K	EY FEATURES	5~6
II. U	NIT PACKAGE	7
III. E	BUTTON AND CONNECTION	8~11
IV. F	REMOTE CONTROLLER	12
V. O	PERATION	13~20
1.	POWER ON	13
2.	LOG IN SYSTEM	13
3.	RECORD	13
4.	LIVE MODE	14~15
5.	SEARCH MODE	16~17
6.	FUNCTION	18~20
VI. S	SYSTEM SETUP	21~40
•	THE TABLE OF MENU	21~22
1.	SYSTEM	23~26
	1-1 PASSWORD	23
	1-2 TIME	24~25
	1-3 PTZF PROTOCOL	25
	1-4 STORAGE	25~26
	1-5 CHANGE LANGUAGE	26
	1-6 SOFTWARE UPDATE	26~27
	1-7 SETUP DATA	27~28
2.	DISPLAY	28~30
	2-1 SEQUENCE DWELL (SINGLE)	- 28
	2-2 SEQUENCE DWELL (GROUP)	- 28
	2-3 CAMERA NAME	28
	2-4 CAMERA STATUS	29
	2-5 CAMERA COLOR	29
	2-6 SPOT DWELL (SINGLE)	29
	2-7 SPOT DWELL (GROUP)	30
	2-8 VGA FREQUENCY CHANGE	
	2-9 VIDEO STANDARD	30
3.	RECORD	31~35
	3-1 REC PROPERTY	31
	3-2 REC OPTIONS	31~32
	3-3 EVENT REC	32~34

3-4 SCHEDULE REC	34
3-5 DELETE REC	35
3-6 LOCK/UNLOCK	35
3-7 DELETE ALL REC	35
4. NETWORK	36~38
4-1 NETWORK TYPE	36
4-2 DDNS	37
4-3 NET PASSWORD	37
4-4 NET CLIENT PORT	37
4-5 NET CLIENT ID	38
4-6 NET DVR ID	38
4-7 NET CLIENT ADDR	38
4-8 NETWORK THROUGHPUT	38
4-9 WEB PORT	
5. SENSOR / AUDIO	39~40
5-1 SENSOR TYPE	39
5-2 ALARM MOTION MANAGER	39
5-3 ALARM SENSOR MANAGER	39
5-4 ALARM BUZZER	40
5-5 ALARM OUTPUT	40
5-6 ALARM OUT PERIOD	40
5-7 AUDIO	40
HDD INSTALLATION	41
TROUBLE SHOOTING	42

KEY FEATURES

Operation

Embedded LINUX OS

Enhanced MPEG4 compression

Display, Playback, Recording, Network transmission

Real time single or multi-screen display

Easy operation by IR remote controller

Hidden camera option (covert)

Easy firmware update by network and USB 2.0

Playback

Multi-screen playback

Search by time, event and calendar with go first/last function

Simple playback – automatic download of viewer software at backup

Recording

Recording resolution and quality level adjustable

Recording frame rate can be set by user

The recording speed of max. 120/100 images per second (NTSC/PAL)

Continuous, manual, schedule and event (motion, alarm) recording

Pre-alarm/post alarm recording

Delete and lock/unlock recording video available

4 channel audio recording

Alarm pop-up

Event log view

Network

Live, playback with viewer software and IE(Internet Explorer)

Remote control via networked PC with the exclusive client viewer

Supporting Static, DHCP, DDNS, PPPoE

Multi-user connection available

Live and Recording audio File play in network

KEY FEATURES

Audio

- 4 channel audio recording in real time
- 1 channel audio output

Backup


Remote backup on network PC with the exclusive client viewer CD-RW (DVD-RW) backup USB 2.0 backup(Both USB stick and USB connection HDD available)

General

Auto detection of video frequency(NTSC/PAL)
Built-in hardware Watchdog
S-Video output
Alarm In/Out, RS-485, RS-232 Connections
Loop-through connections
Multiple Languages
VGA output for PC monitor




MPEG4 DVR System







1-1 FRONT PANEL



1. Channel Selection

You select a channel as full-size screen during live display or playback. When the number is above 10, please press the '+10' button at first and press other number.

2. USB 2.0 slot

It is used when you upgrade firmware update and backup video files.

3. MULTI

When you press the button repeatedly, you can change the screen display mode as you want from PIP to multi channel to single channel view.

4. AUTO

The function allows users to watch individual channels by rotating every channel in turn automatically. Please press the button again to stop it

5. PIP (Picture in Picture)

If you press the button, you can see a master channel and a slave channel on the master simultaneously. Press the button again, and master becomes slave and vise versa.

6. MUTE

You can turn off the audio.

7. INFO

INFO key shows system information of DVR only in live display mode.

8. OSD

If you do not need OSD, press the button. Pressing one more time retrieve the OSD.

9. BACKUP

You can backup video in CD-RW (DVD-RW) or USB (Memory stick and exterior HDD) in playback mode.

10. LED Lights

You can identify how power, record, HDD and network(NET) are.

11. MENU

You can change DVR settings. When you want to return to the previous step, press the button again.

12. SEARCH

You can choose the video file you want to find through this key.

13. REC

You can manually record by pressing the button. Press it once more, and you can stop recording.

14. Playback

REW (◀ ◀): Rewind the video (up to 128x) **PLAY/PAUSE** (▶/II): Play and Pause the video **FAST** (▶ ▶): Fast forward the video (up to 128) **STOP** (■): Stop the video.


15. PTZ


When you want to control speed dome cameras, please press the button.


16. Control keys

You can shift up, down, right and left and select what you want to.

1-2 REAR PANEL







1. Audio In

RCA 4 channel audio inputs

2. Video Input

Max 16 channel video inputs

3. Loop out

Max 16 channel video loop outputs

4. Power switch

5. Power Input

Input: 100V~240VAC 50/60Hz 1.5A Output: DC 12V, 5A

6. SEN. IN/AL/485

Sensor In:16Ch(1~16), 9Ch(1~9), 4Ch(1~4) 17-20: Alarm Out, 21: 485+, 22: 485-, 23-25: GND

7. RS232

Connection port for engineering use only

8. VGA

VGA output connecting to LCD monitor

9. USB

USB 2.0 for system update and video backup

10. LAN

LAN connecting to a variety of networks

11. Audio Out

RCA 1 channel audio output

12. S-Video

Connecting to S-Video monitor


13. Video Out

Connecting to monitor

KPD-M401: 2 outputs, KPD-M901/1601: 1 output

14. Spot Out (*KPD-M901/1601)

Connecting to spot monitor



1. REC (Record)

2. Channel Selection

You select a channel as full-size screen during live display or playback. When the number is above 10, please press the '+10' button at first and press other number.

3. REC STOP: Record stop button

4. INFO: DVR Information

5. P/T: Pan, Tilt

6. Z/F: Zoom, Focus

7. OSD: OSD on/off

8. MENU

9. LOG: Log list view

10. SEARCH

11. Direction keys(\triangle , ∇ , \triangleleft , \triangleright)

: Move cursor or control PTZF Camera

12. MUTE

13. BACKUP

14. Playback control keys

15. SPOT

16. PIP

17. POP

18. AUTO

19. Multi display modes

HDD INSTALLATION

1. Power on

Press power button on rear of the unit.



If system begins, loading message will appear. (It takes around 30seconds to boot DVR system)

2. Log in system

Enter your password (Default: 0000) to Login the system

ENTER PASSWORD

NOTE a. To change your password, please refer Page 23.

b. Administration password pops up when users press MENU button.

ENTER ADMIN PASSWORD

3. Record


Press REC button to record the video. If you press REC button once more, recording will be stopped.

BEFORE RECORDING, PLEASE CHECK!!


- (1) Check out whether the date and time are correctly set.
- (2) Check out whether HDD is formatted. If HDD is not formatted, please format HDD.
 - → Please refer **Page 27** to format HDD
- (3) Make sure that each camera screen displays properly.
- (4) Set up the camera channel name.
- (5) Select recording quality.
- (6) Select recording method.
- (7) Recording can be stopped by pressing REC button again. To keep recording, we recommend you to set recording mode in "CONTINUOUS".

→ Please refer *Page 31.*

4. Live mode



4.2 Display of full screen mode



4-3. Quad screen (*Remote control)

To see quad screen when the full screen mode, press button.

To see specific camera by full screen, press button

4-5. 9ch display mode (*Remote control) * KPD-M901 / M160

To see cameras by 9ch mode, press butto

4-6. 16ch display mode (*Remote control) * KPD-M1601

To see camera by 16ch mode, press button

4-7. POP mode (*Remote control) * KPD-M901 / M1601

Press POP button to enlarge specific camera. Whenever pressing POP button, go to next camera.

POP

4-8. Auto Sequence (Auto)

- Interval display on the monitor before going to the next channel.
- the default time span from one channel to another is 2 seconds.
- User can select the range of time from 1 to 60 seconds.

HDD INSTALLATION

If you want to change interval time to rotate the camera, please go to 'MENU' and setup the interval time.

4-9. PIP

When it is in full screen display mode, you can see other camera in a small window.


- (1) Press PIP button of remote controller to go to PIP mode
- (2) If you press this button in PIP mode, the position of two cameras will be swapped.



(3) Press Camera button in PIP mode to change small screen to another camera.



(4) Press Direction button to move small window at appropriate position.



5. Search mode

- (1) Press Search button
- (2) Select Search method by using ▲▼ button and press 'ENTER' button

TIME SEARCH	Search data by Year /Month/Day/Time			
EVENT SEARCH	Search only Data recorded by motion detection function			
CALENDAR SEARCH	Search data in calendar			
GO FIRST	Search from the top of the list			
GO LAST	Search from the bottom of the list			

[SEARCH]
* TIME SEARCH
* EVENT SEARCH
* CALENDAR SEARCH
* GO FIRST
* GO LAST

5-1. TIME SEARCH

[TIME-SEARCH] YEAR : 0000 MONTH: 00 DAY : 00 TIME : 00:00

- (1) If you select TIME SEARCH, Time Search table will appear
- (2) Key in the year, month, day and time that you want to search for.
- (3) Press the Enter key.

5-2. EVENT SEARCH


- (1) If you select EVENT SEARCH, the calendar will appear.
- (2) Select desired date by using ◀▶▲▼ button and press 'ENTER' button





EVENT LIST	1/2
0013 060910:230233 FL MD 01 08	09
0012 060910:225033 FL MD 01 07	09
0011 060910:224233 FL MD 01 08 (09
0010 060910:223233 FL MD 01 08	16
0009 060910:215233 FL MD 01 08	09
0008 060910:213233 FL MD 01 08	09
0007 060910:210233 FL MD 01 08	09
PGDN:< PGUP:> LAST:<< FII	RST:>>
I	

(3) Select desire video clip in the list by using ▲▼ button and press 'ENTER' button.




5-3. CALENDAR SEARCH

- (1) If you select CALENDAR SEARCH, the calendar will appear.
- (2) Select desired date by using ◀▶▲▼ button and press 'ENTER' button
- (3) Select hour and minute that you want to search. The hour bar is divided into 24 sectors (unit of one hour), and the minute bar is done into 30 sectors (unit of two minutes).

<<2006-09>>						
SUN	MON	TUE	WED	THU	FR I	SAT
					1	2
3	4	5	6	7	8	9
10	11	12	13	14	15	16
17	18	19	20	21	22	23
24	25	26	27	28	29	30





5-4. GO FIRST

(1) If you select GO FIRST, you can play back from the top file of the list to bottom.

5-5. GO LAST

(1) If you select GO LAST, you can play back from the bottom of the list.

5-6. Playback

- If you press Play button in live mode, the video clip recorded recently will be played.
- If you want to see specific camera by full screen, press camera button.
- For display of quad mode from full screen, press quad button.
- You can control playback speed with ◀ ◀ / ▶ ▶ button. Once you press the

	Tod dail delia of play back opeda illa.				
44	REWIND / Frame by frame	 - X2, X4, X8, X16, X32, X64, X128 - Reduce Fast Forward speed while Fast Forward play - Reverse playback frame by frame during PAUSE mode 			
▶I	PLAY / PAUSE	Play the video and pause the video			
>>	FAST FORWARD / Frame by frame	 - X2, X4, X8, X16, X32, X64, X128 - Reduce Fast Reward speed while Fast Rewind - Forward play frame by frame during PAUSE mode 			
	STOP	Stop the playback and go to Live mode			

6. Function

6-1. INFO

Show the present status of DVR system

If you press direction button (▶), detailed information is shown.

(Normal information → REC information → S/W information → HDD information)

[STATUS]

S/W VERSION: VO.9.0-BY-16

(07/11/05 20:40)

[HDD] MA:75G (10%) SL1: NONE SL2:36G(0%) SL3: NONE

NETWORK: STATIC 192.168.1.200

MAC: 00.0E.B5.00.0C.B6 DDNS: DDNS OFF

WEB PORT: 80

NEXT INFO: RIGHT KEY



				▼			
Ī	[REC]						
			SIZE:	360	X240		
l	CH	RATE	QUALITY	CH	RATE	QUALITY	
l	1	30	NORM	9	30	NORM	
l	2	30	NORM	10	30	NORM	
l	3	30	NORM	11	30	NORM	
l	4	30	NORM	12	30	NORM	
l	5	30	NORM	13	30	NORM	
l	6	30	NORM	14	30	NORM	
l	7	30	NORM	15	30	NORM	
l	8	30	NORM	16	30	NORM	
1							

KERNEL : Unknown

BOOT LOADER: Unknown ENC. FIRMWARE: 20051031_0 DEC. FIRMWARE: 20051031_0

APPLICATION: 1.0.7 UI VER: 1.0.5-F16 DECODER VER: 1.4.0-0 ENCODER VER: 1.0.2-1 NETWORK VER: 1.0.5-3 DB VER: 1.0.1-3



20050427_162000_pCw.ps SL1 : HARD DISK NOT EXIST

SL2: CD-ROM

SL3: HARD DISK NOT EXIST

S/W VERSION	Software version		
HDD	Indicate each HDD capacity and Used capacity		
NETWORK	Indicate the information of Static or Dynamic IP address		
MAC	Indicate DVR own MAC address		
DDNS	Indicate the statue of DDNS service		
[REC]			
SIZE	Recording resolution		
СН	Camera No.		
RATE	Statue of frame rate for recording		
QUALITY	Indicate recording quality (BEST/HIGH/NORMAL/BASIC)		

6-2. MUTE



When you press MUTE key, AUDIO setup window appears. Press the enter key when you set mute mode or Audio on. FYI, Audio works only full screen mode.

[AUDIO]
STATUS: ▷ MUTE

6-3. BACKUP



User can backup the data to USB stick (USB HDD) or built-in CD (DVD)-RW.

- (1) Connect USB equipment to USB port of DVR system.
- (2) Press 'BACKUP' button.
- (3) Select a method and press 'ENTER' button.

[BACKUP]
MEDIA TYPE: ▷ CD-R FILE FORMAT: ▷ NATIVE BACKUP BASE: ▷ FILE CHANNEL: ▷ ALL [*] 1 [*] 2 [*] 3 [*] 4 [*] 5 [*] 6 [*] 7 [*] 8 [*] 9 [*] 10 [*] 11 [*] 12 [*] 13 [*] 14 [*] 15 [*] 16 START: END:
TOTAL SIZE: 0M
BACKUP FORMAT MEDIA

MEDIA TYPE	CD-R CD-RW DVD-R DVD-RW USB MEMORY	① Select device to backup	
FILE FORMAT	NATIVE	② Select backup file	
BACKUP BASE	FILE TIME	③ Select backup type	
CAMERA	ALL [.]1~[.]16	④ Select camera to backup	
START	⑤ Start time to backup file		
END	6 End time to backup file		
TOTAL SIZE	⑦ Indicate total size to backup		

- Select BACKUP and press 'ENTER' button
- (9) In case of CD/DVD-RW, you can erase data in media by FORMAT MEDIA.

6-4. PTZ (Pan / Tilt)

Press the PTZ button. Users can control PAN/TILT camera by direction button.

PTZF
<< CH: 01 >>
<< PAN >>
<< TILT >>
<< ZOOM >>
<< FOCUS>>




CH: 01	Press direction button to set the PTZ camera channel.
PAN	Press direction button to move camera up and down.
TILT	Press direction button to move camera right and left.
ZOOM	Press direction button to zoom in and out.
FOCUS	Press direction button to focus the video images.

6-5. LOG LIST (*Remote controller only)

Show all information about what happened to DVR system during operation.

[EVENT LOG VIEW]		
EVENT TYPE: A MOTION: [.] ALARM: [.] SYSTEM: [.] FILE: [.] POWER: [.] FROM: 2005-11- TO: 2005-11-05 OK	SENSOR: [.] V-LOSS: [.] HDD : [.] DB : [.] NET : [.]	



* Example of Log list



Event	Meaning	Description	
MD	Motion Detection	Detect motion	
SD	Sensor Detection	Detect sensor	
VL	Video Loss	No video	
SY	System	Change system setup	
FL	File	Delete or Create a file	
PW	Power	Power On / Off	
NT	Network	Access system by network	
HD	HD Hard Disk Information of HDD		
DB	Data Base	Information of data base	

Tips for setup of DVR system

- (1) Press 'MENU' button to setup DVR system.
- (2) The window for password input will appear.
- (3) Enter your Password. (Default: 0000)
- (4) Select desired sub-menu item with Direction button.
- (5) Press 'ENTER' button to go to submenu or save system.
- (6) Press 'MENU' button to go to previous mode without save or escape system menu.
- (7) How to use text input dialog box when you need to input a text to system
 - When text input dialog box appears, select desired alphabet and mark by Direction button.
 - 2) Press 'ENTER' button to input text.
 - 3) Then, the selected text will appear.
 - 4) Press 'MENU' button to quit dialog box.

```
[TEXT INPUT DIALOG]
ABCDEFGHIJ
KLMNOPQRST
UVWXYZ←
abcdefghIj
klmnopqrst
uvwxyz.~/:
0123456789
_-@SPACE

CH01
------
```

The Table of MENU

MENU	SUB MENU		DESCRIPTION	
		1-1-1.ADMIN PASSWORD	Change system password for administrator	
	1-1.PASSWORD	1-1-2.USER PASSWORD	Change system password for user	
		1-1-3.PASSWORD CHECK	Activate system password	
		1-2-1.TIME SETUP	Setup current time	
	1-2.TIME	1-2-2.TIME FORMAT	Setup time format	
1. SYSTEM		1-2-3.TIME OSD FORMAT	Set TIME OSD color and position on screen	
	1-3.PTZF PROTOCOL		Set PTZF cameras	
	1-4.STORAGE		Format HDD / Overwrite setting	
	1-5.CHANGE LANGUAGE		Change Language of Menu	
	1-6.SOFTWARE UPDATE		Upgrade System Software	
1-7. DEFAULT SETUP		ETUP	Set the system as to factoring default	
	2-1.SEQUENCE DWELL(SINGLE)		Set switching time interval on Live full display	
	2-2.SEQUENCE	DWELL(GROUP) * 9/16ch	Set switching time interval on Live quad display	
0 DIODI AV	2-3.CAMERA NAME		Input Camera name	
2. DISPLAY	2-4.CAMERA STATUS		Show or Hide a specific camera	
	2-5.CAMERA CO	DLOR	Control the color of camera	
	2-6.SPOT DWELL (SINGLE) * 9/16ch		Set switching time interval on full display of Spot	

OPERATION

	2-7.SPOT DWELL (GROUP) * 9/16ch	Set switching time interval on quad display of Spot
	2-8.VGA FREQUENCY CHANGE	Change VGA frequency
	2-9.VIDEO STANDARD	Set the video standard
	3-1.REC PROPERTY	Set recording property (Resolution/Quality/Frame rate)
	3-2.REC OPTIONS	Set recording option (Continuous / DEINTERLACE / Water mark)
	3-3.EVENT REC	Set Motion / Sensor
3. REC	3-4.SCHEDULE REC	Set schedule recording
	3-5.DELETE REC	Delete record file
	3-6.LOCK/UNLOCK REC	Protect specific file from delete
	3-7.DELETE ALL REC	Delete all files
	4-1.NETWORK TYPE	Set the present network system (Static / Dynamic)
	4-2.DDNS	Set network for DDNS
	4-3.NET PASSWORD	Assign password to access the DVR system by Net-client software
	4-4.NET CLIENT PORT	Assign port for port-forwarding in user's router
4. NETWORK	4-5.NET CLIENT ID	Assign additional ID and password to access the DVR system by Net-client software
	4-6.NET DVR ID	For system check of net client when network connection
	4-7.NET CLIENT ADDR	Limit Client IP address to access DVR system * With only registered IP address, allow user to access DVR system
	4-8.NETWORK THROUGHPUT	Set the speed of data transmission in DVR system
	5-1.SENSOR TYPE	Set present network system (Static / Dynamic)
	5-2.ALARM MOTION MANAGER	Set Alarm output when motion is detected
5. SENSOR / SOUND	5-3.ALARM SENSOR MANAGER	Set Alarm output when sensor is detected
	5-4.ALARM BUZZER	Set Alarm buzzer ON/OFF
	5-5.ALARM OUTPUT	Set Alarm output ON/OFF to each camera
	5-6.ALARM OUT PERIOD	Set working time of Alarm output
	5-7.AUDIO	Set audio on designated channel

1. SYSTEM

1-1. PASSWORD

1-1-1. ADMIN PASSWORD



Admin password is for administrator. With this password, user can access to all menus of system. Password consists of only four digit numbers.

- (1) Enter new Password to change by using Number button.
- (2) Enter new Password again to confirm the Password.



1-1-2. USER PASSWORD

- (1) Enter new Password to change by using Number button.
- (2) Enter new Password again to confirm the Password.



1-1-3. PASSWORD CHECK

(1) Select desire sub-menu to setup by using ▲▼ button and press 'ENTER' button ADMIN: Access all system [CHECK PASSWORD]

USER: Only for logging on system

(2) Select OFF or ON ON: can access the system after confirmation of Password



(3) Press 'MENU' button to go to previous mode.

in case you forgot the passwords, please press the keys in the remote controller.

INFO->MUTE->SEARCH->■->|

When you press the keys in turn, you can see 'Factory Setup' mode to reset the password again. If the reset password works correctly, you have to set the DVR into the factory default in System menu.

1-2. TIME

1-2-1. TIME SETUP

- (1) Select desired sub-menu by direction button and enter **Year / Month / Day / Time** by using Number button.
- (2) New window will appear. Press 'ENTER' button to change time. If you really want to change, press Yes, otherwise No.

TIME SETUP

YEAR : 0000

MONTH: 00

DAY : 00

TIME : 00:00




WARNING!!!

TIME WILL BE CHANGED
THE FILES AFTER CHAHGED
TIME WILL BE DELETED

Are you sure?
[ENTER] → YES, [MENU]→ NO



If you change the date/time to previous date/time, previous recorded data can be deleted as follows. So, strongly recommended to backup data before changing time.



1-2-2. TIME FORMAT

(1) Select desire TIME format by direction button and press 'ENTER' button.

[TIME FORMAT]
- YY / MM / DD
- DD / MM / YY
- MM / DD / YY

If the date is Dec 30 th 2006		
FORMAT DISPLAY		
YY/MM/DD	2006/12/30	
DD/MM/YY	30/12/2006	
MM/DD/YY	12/30/2006	

<Format description>

1-2-3. TIME OSD FORMAT

(1) Select desire position and color of time format and press 'ENTER' button.

[TIME OSD FORMAT] TOP-WHITE TOP-BLACK BOTTOM-WHITE BOTTOM-BLACK OFF




1-3. PTZF PROTOCOL

(1) In PTZF protocol menu, select sub-item of desire camera and press 'ENTER' button to set

		[PTZF PRO	TOCOL 1		^
СН	ID	PROTOCOL	BAUD	SPEED	\triangle
01	⊳000	⊳PELCO_D	⊳2400	⊳9	\Box
02	⊳000	⊳PELCO_D	⊳2400	⊳9	
03	⊳000	⊳PELCO_D	⊳2400	⊳9	
04	⊳000	⊳PELCO_D	⊳2400	⊳9	Ч
05	⊳000	⊳PELCO_D	⊳2400	⊳9	
06	⊳000	⊳PELCO_D	⊳2400	⊳9	Δ
					•

- (2) ID: Enter PTZF camera ID (From 000 to 255)
- (3) PROTOCOL: Select appropriate protocol.
- * Available protocol: Pelco D, Pelco P, Chubb i SD, COP, LILIN, CYNIX, DSC230...
- (4) BAUD: Select appropriate BAUD rate
- (5) SPEED : Select desire speed for Pan tilt camera
- (6) Press 'MENU' button to finish the setting

1-4. STORAGE




1-4-2. FORMAT

When you install HDD in DVR system, you need to format HDD.



- Make sure that Format function will erase all data file in HDD, which is an unrecoverable command.
- Completing the formatting, the message ("DISK FORMAT COMPLETE") will appear. Press the MENU button, and it returns to STORAGE window. If there's more HDD to format, you can format them again. If not, press MENU button. DVR will reboot automatically.





When the HDD detection status is "N/F", recording function doesn't work. You have to format the HDD in N/F before recording.

1-5. CHANGE LANGUAGE


- (1) Press 'ENTER' button "Change Language".
- (2) Select desired language and press 'ENTER' button.

[CHANGE LANGUAGE] **ENGLISH PORTUGUESE** RUSSIAN

1-6. SOFTWARE UPDATE

There are two methods to upgrade the DVR system.

USB UPDATE: Upgrade the DVR system by using USB memory stick.



After software update, user must turn DVR into Default values in SYSTEM.

1-6-1. USB UPDATE



(1) Copy provided Firmware file to your USB memory stick

The firmware file should be in Root directory of USB memory NOTE

- (2) Connect USB memory stick to USB port in unit.
- (3) Press 'MENU' button and go to Software Update
- (4) Select USB UPDATE and press 'ENTER' button to proceed with software upgrade.
- (5) After completing upgrade, the system will reboot automatically.
- (6) Then, Check S/W version through INFO menu.

1-6-2. NETWORK UPDATE

[SOFTWARE UPDATE]
- NETWORK UPDATE

- USB UPDATE



[SOFTWARE UPDATE-NETWORK] SERVER IP : videonetserver.com FILE NAME : kpro-16.tar.gz

UPDATE CANCEL

- (1) Check the unit is connected to the Internet.
- (2) Press 'MENU button' and go to Software Update.
- (3) Check Server IP and File name whether it is correct to download. If it is wrong, select Server IP and File name and press 'ENTER' button to input new information by Text input Dialog box.

NOTE

Make sure the information of Server IP & File name through your supplier.

- (4) Select 'UPDATE' and press 'ENTER' button to proceed with Software upgrade.
- (5) After completing upgrade, the system will reboot automatically.
- (6) Then, Check S/W version by press INFO button

1-7. SETUP DATA

KPD-M series supply users with another convenient function. In case users have to setup the menus of several DVR in the same modes, SETUP DATA function reduce the repeated labor by backing up and restoring the menu setup through USB.

1-7-1. BACKUP SETUP DATA

Users can backup the current menu setup for the other DVR menu setup.

1-7-2. RESTORE SETUP DATA

Users can restore the backed-up menu setup for the other DVR menu setup.

1-7-3. DEFAULT SETUP

BACKUP SETUP DATA

Connect USB-Memory and
Press ENTER to continue
[ENTER]->YES, [MENU]->NO

RESTORE SETUP DATA

Connect USB-Memory and Press ENTER to continue [ENTER]->YES, [MENU]->NO


[DEFAULT SETUP]
WARNING
Are You Sure?
['ENTER'] ->YES , ['MENU']->NO

Press 'ENTER' button to initialize the system in default setup mode.

2. DISPLAY

2-1. SEQUENCE DWELL(SINGLE)

- (1) In Sequence dwell menu, select desired Camera by using ▲▼ button and press ENTER button.
- (2) Input desired second by using number button and press 'ENTER' button to finish the setting.





- Maximum time is up to 60 seconds.
- If you want to cancel, press 'MENU' button.

2-2. SEQUENCE DWELL(GROUP) * KPD-M901 / M1601

- (1) In Sequence dwell menu, select desired quad no. by using ▲▼ button and press 'ENTER' button.
 - 04 ⊳03

[S.DWELL(GROUP)] NO

01

02

03

SEC

⊳03

⊳03

⊳03

- (2) Input desired second by using number button and press 'ENTER' button to finish the setting.
 - NOTE
- Can enter maximum up to 60 seconds
- If you want to cancel, press 'MENU' button.

Group No. Camera	
1	Channel 1 ~ Channel 4
2	Channel 5 ~ Channel 8
3	Channel 6 ~ Channel 9

Group No.	Camera
1	Channel 1 ~ Channel 4
2	Channel 5 ~ Channel 8
3	Channel 9 ~ Channel 12
4	Channel 13~ Channel 16

[KPD-M901] [KPD-M1601]

2-3. CAMERA NAME


- (1) Select desired camera by using ▲▼ button and press 'ENTER' button.
- (2) TEXT INPUT DIALOG window will appear.
- (3) Enter desired camera name and press 'MENU' button to finish input

NO 01 02	[CAME NAME CH 01 CH 02	NO 09	ME] NAME CH 09 CH 10	
03	CH 03	11	CH 11	
08	CH 08	16	CH 16	

2-4. CAMERA STATUS

- (1) Select the camera and press 'ENTER' button in Camera status mode.
- (2) Select desire sub-item and press 'ENTER' button.

SHOW: Display the camera on monitor **HIDE**: Not display the camera on monitor






- Even if a camera is set in hide mode, the camera actually is recorded.
- Hidden camera won't be displayed on playback mode also.

2-5. CAMERA COLOR


- (1) Select a desired camera by direction button and press 'ENTER' button
- (2) Select desired item and Press ◀▶ button to 'ENTER' the value.



- button : + (increase value) : -125




(3) Press 'ENTER' button to finish the setting. ('MENU' button: Cancel the setting)



2-6. SPOT DWELL(SINGLE)

* KPD-M901 / M1601

- Select desired Camera by using ▲▼ button and press ENTER button.
- (2) Input desired second by using number button and press 'ENTER' button to finish the setting.





- Can enter maximum up to 60 seconds.
- If you want to cancel, press 'MENU' button.

2-7. SPOT DWELL(GROUP) * KPD-M901 / M1601

- Select desired Camera by using ▲▼ button and press 'ENTER' button.
- (2) Input desired second by using number button and press 'ENTER' button to finish the setting.



- Can enter maximum up to 60 seconds
- If you want to cancel, press 'MENU' button.

Group No.	Camera
1	Channel 1 ~ Channel 4
2	Channel 5 ~ Channel 8
3	Channel 6 ~ Channel 9


Group No.	Camera
1	Channel 1 ~ Channel 4
2	Channel 5 ~ Channel 8
3	Channel 9 ~ Channel 12
4	Channel 13~ Channel 16

[KPD-M901]

[KPD-M1601]

2-8. VGA FREQUENCY CHANGE

- (1) Press 'ENTER' button in Change VGA freq.
- (2) Select desired video frequency.



2-9. VIDEO STANDARD

NOTE

(1) Select your video system

AUTO DETECTION: Set video automatically.

SWITCH: Set video according to jumper on main board.

 $\ensuremath{\mathsf{NTSC}}$: Set video to NTSC system.

PAL: Set video to PAL system.

After changing Video standard, DVR system will reboot automatically

[VIDEO STANDARD]

> AUTO DETECTION

> SWITCH

> NTSC

> PAL

3. REC

3-1. REC PROPERTY.

Select desired item and press 'ENTER' button to change value.

REC RI	ESOLUTION :	[SETUP-RE0 ▷ 720X480	C-PROPE	ERTY]	
CH 01 02	QUALITY > HIGH > HIGH	RATE ▷ 2 ▷ 2	CH 09 10	QUALITY > HIGH > HIGH	RATE ▷ 2 ▷ 2
03 08	▷ HIGH▷- HIGH	≥ 2≥ 2	11 16	▷ HIGH□ HIGH	▷ 2 ▷ 2

3-1-1. REC resolution

(1) Select desired resolution and press 'ENTER' button

RESOLUTION

- 720 X 480 - 720 X 240
- 320 X 240

3-1-2. Quality

(1) Select desired quality and press 'ENTER' button

QUALTY

- BEST
- HIGH
- NORMAL
- BASIC

3-1-3. Rate

(1) Select desire frame rate by ◀▶ button and press 'ENTER' button



- (2) Non-available frame in each resolution mode will be indicated as Red color.
- (3) Press 'MENU' button to save and go to previous mode.

3-2. REC OPTIONS

[REC OPTION]

RECORD CONTINUOUS : ▷ **OFF**PLAY DEINTERLACE ▷ ON

WATER MARK ▷ OFF

3-2-1. RECORD CONTINOUS

ON: DVR system will record always. Cannot stop recording by manual operation.

[REC CONTINUOUS]

- ON

- OFF

OFF: DVR system will record in manual operation.



If REC-CONTINUOUS IS **OFF**, anybody can stop recording by record stop button. So, recommended to set **REC-CONTINUOUS** mode to **ON**.

3-2-2. PLAY DEINTERLACE

When displaying playback recorded by 720X480 resolution through analog monitor, there can be flickering of image. With this function, you can see smooth display.

[PLAY DEINTERLACE] - ON - OFF

3-2-3. WATER MARK

With this function, users can protect recorded data not to modify image. If there is any attempt to modify the video, the video cannot be played.

[WATER MARK] - ON - OFF

3-3. EVENT REC


[EVENT]
- MOTION DETECTION


- SENSOR DETECTION
- OPTIONS

3-3-1. MOTION DETECTION

[EVENT REC(M/D)]						
NO	SEN	AREA	ОN	SEN	AREA	
01	\triangleright 0	⊳off	09	\triangleright 0	⊳off	
02	\triangleright 0	⊳off	10	\triangleright 0	⊳off	
03	\triangleright 0	⊳off	11	\triangleright 0	⊳off	
08	⊳ 0	⊳OFF	16	⊳ 0	⊳OFF	

(1) Select desired camera to set motion detection and press 'ENTER' button







Sensitivity rate : 0(Low) <1<2.....<8<.9(High)


- AREA : Adjust the area of motion

.ALL: select all area

.PART : Select desired area.

.OFF: Quit motion detection function.

[AREA] - ALL - PART - OFF




will change to set like side picture. Select desire area with direction button and press 'ENTER' button to select area. To cancel the selected block, press 'ENTER' button one more.

3-3-2. SENSOR DETECTION

Select desire position and press 'ENTER' button.

: Sensor detection ON : Sensor detection OFF



3-3-3. OPTIONS

Set recording options when event happens.

[EVENT-OPTIONS]

POST-RECORD TIME : ▷ 10SEC

PRE-RECORD TIME : ▷ 4SEC

POP-UP SCREEN : ▷ ON

3-3-3-1. POST-RECORD TIME

; Set recording time after Event occurs

3-3-3-2. PRE RECORD TIME

; Set recording time before Event occurs

[POST REC TIME]
- 10SEC
- 30SEC

- 1 MIN

- 5 MIN - 10MIN

[PRE REC TIME]

- NO PRE REC
- 2SEC
- 4SEC
- 6SEC
- 8SEC - 10SEC

3-3-3-3. POP UP

ON: When event happens in specific camera, the camera will be popped up.


OFF: The popup function is off.

[POP UP SCREEN]
- ON
- OFF


3-4. SCHEDULE REC

Users can set up the schedule recording on desired channel, date and time.

(1) Select desired camera to record by schedule and press 'ENTER' button.



(2) Select desire position for a day of week & time and press 'ENTER' button



Example) System will record from 10:00 to 14:00 on Tuesday

3-5. DELETE REC

- (1) Select desired data clip and press 'ENTER' button.
- (2) New window announcing WARNING will appear.
- (3) Press 'ENTER' button to delete selected data clip. ('MENU' button : cancel)

```
FILE LIST – DELETE
                            1/105
0338 20050806_125000 600S D L W
0338
     20050806_125000 600S D U W
     20050806_125000 600S D U W
0338
0338 20050806_125000 600S D U W
0338 20050806 125000 600S D U W
0338 20050806_125000 600S D U W
0338 20050806_125000 600S D U W
     20050806_125000 600S D U W 20050806_125000 600S D U W
0338
0338
0338 20050806_125000 600S D U W
PGUP: < PGDN: > LAST: 《 FIRST: 》
```

[WARNING!!!] DELETE FILE 0338 20050806_125000 600S D U ARE YOU SURE? ['ENTER']→YES ['MENU']→NO

3-6. LOCK / UNLOCK REC



You can preserve some desired data with this function. The locked data will **NOTE** be marked to 'L' and will not be erased on overwriting of HDD.

(1) Select desired file to protect and press 'ENTER' button.

```
FILE - LOCK/UNLOCK
0338 20050806 125000 600S D U W
0338 20050806_125000 600S D L W
                                              Protected file
0338 20050806_125000 600S D U W
PGUP: < PGDN: > LAST: < FIRST: >
```

3-7. DELETE ALL REC

(1) Press 'ENTER' button to delete all data ('MENU' button : Cancel)

```
[WARNING!!!]
ALL RECORDED FILE
WILL BE DELETED
ARE YOU SURE?
['ENTER'] -> YES
                    ['MENU'] -> NO
```



You can't delete files while recording. Please stop recording if you delete files.

OPERATION

4. NETWORK

4-1. NETWORK TYPE

(1) Select network type according to your network system.

NETWORK TYPE STATIC DYNAMIC PPPOE

STATIC : Static IPDYNAMIC : Dynamic IP

PPPOE: when your system is connected to ADSL modem

(2) STATIC IP

 Enter IP ADDRESS / GATEWAY / SUB-NETMASK by using number key

2) Press 'ENTER' button to save.

[STATIC IP]
IP ADDRESS
XXX.XXX.XXX
GATEWAY
XXX.XXX.XXX
SUB-NETMASK
XXX.XXX.XXX

(3) DYNAMIC IP

 If you select Dynamic IP, system will detect IP address automatically and show IP information. [DYNAMIC IP]
IP ADDRESS
XXX.XXX.XXX.XXX
GATEWAY
XXX.XXX.XXX.XXX
SUB-NETMASK
XXX.XXX.XXX.XXX

(4) PPPOE (for ADSL)

; If your network system is ADSL, you need to enter your ID (NAME) and password (AUTH) to access Internet. If you don't know your ID &

[PPPOE] NAME : XXXX AUTH : XXXXX

Password, please ask your ISP supplier of your ID & Password.

4-2. DDNS



- This is for user who is using dynamic IP. With this function, user can use dynamic IP like static IP
- This system supports two website at www.dyndns.org and www.ipupdater.com
- For details, please refer network manual.

[DDNS]
DOMAIN:
USER ID:
GROUP ID:
PASSWORD:
ACTIVATE:<-NO>

Domain: input your domain name of DDNS website

User ID : input your ID of DDNS web site

Group ID: input your group ID of DDNS web site **PASSWORD**: input password of DDNS web site **Activate**: Select website that you registered to

activate DDNS function.

NO videonet.co.kr

Example)

[DDNS]

DOMAIN: kpro.dyndns.org

USER ID : kpro GROUP ID : XXXXX PASSWORD : 1234

ACTIVATE: videonet.co.kr

4-3. NET PASSWORD

- (1) Enter new NET Password to change by Number button.
- (2) Enter new NET Password again to confirm the Password.

[PASSWORD]
'ENTER' NEW NETWORK PASSWORD
:____

[PASSWORD]
CONFIRM NEW NETWORK PASSWORD
:____

4-4. NET CLIENT PORT

- (1) Press 'ENTER' button in net client port mode.
- (2) Select desire port rate and press 'ENTER' button
- (3) Press 'MENU' button

[CLIENT PORT] **PORT AREA PORT AREA** : **⊳7620-7624** -7620-7624 PORT1(LOGON) 07620 -7630-7634 PORT2(CONTROL): 07621 -7640-7644 PORT3(LIVE) 07622 -7650-7654 PORT4(PLAY) 07623 -7660-7664 POR51(BACKUP) 07624


4-5. NET CLIENT ID

- Press 'ENTER' button to input ID & Password in net client ID mode.
- (2) Enter name by TEXT INPUT DIALOG and press 'MENU' button when you finish.

	[CLIENT ID]		
	LOGIN-ID	:	PASSWORD
1		:	
2		:	
3		:	
4		:	
I			

4-6. NET DVR ID

(1) Press 'ENTER' button to input ID in net DVR ID mode.




(2) Enter name by TEXT INPUT DIALOG and press 'MENU' button to save.



- This function is for system check when network connection.
- It's not necessary to set this menu for network connection.

4-7. NET CLIENT ADDR

 Enter IP address by using number key to register IP address that can access to the system.



CLIENT IP 01:

CLIENT IP 10:

[CLIENT IP]

000.000.000.000


000.000.000.000



Can register maximum 10 IP address to access the system.

4-8. NETWORK THROUGHTPUT

- (1) Press 'ENTER' button.
- (2) Then, sub-menu will appear.
- (3) Select desire speed rate and press 'ENTER' button.



4-9. WEB PORT


When remote-access with Web-browser, default web-port is port # 80, but you can assign you own specific web-port, such as port 8080 or 1080, as an Web port.

Enter Number (0000~9999) 0000

5. SENSOR / SOUND


5-1. SENSOR TYPE

- (1) Select connected sensor No. and press 'ENTER' button.
- (2) Select Sensor type and press 'ENTER' button.



5-2. ALARM MOTION MANAGER

- ; If camera detects motion, designated alarm will output.
 - (1) Select Camera no & Alarm no and press 'ENTER' button.
 - (2) Press 'MENU' button to save.




■ : Alarm out ON
□ : Alarm out OFF

If Motion is detected at Camera No.11, Alarm No 2,3 will output

5-3. ALARM SENSOR MANAGER

- ; If sensor is detected, designated alarm will output.
 - (1) Select Sensor no & Alarm no and press 'ENTER' button
 - (2) Press 'MENU' button to save



5-4. ALARM BUZZER


ON: Alarm buzzer is working when sensor signal is detected.

OFF: Buzzer OFF.

- ON - OFF


5-5. ALARM OUTPUT

- (1) Select desire Alarm no and press 'ENTER' button
- (2) Select ON or OFF and press 'ENTER' button




5-6. ALARM OUT PERIOD

- (1) Press 'ENTER' button in Alarm out period mode..
- (2) Select desire period of alarm out and press 'ENTER' button



5-7. AUDIO * KPD-M901/M1601

Select the channel connected to audio and press 'ENTER' button.



HDD INSTALLATION



1. Unscrew the top cover of DVR.



2. Assemble hard disks and HDD bracket the same as the picture. Please be noted that that bracket has front and rear. You must put HDD in right direction.





3. Install the HDDs assembled in the bracket at the designated spot.



The cables connected to the front board should be under the HDD bracket.



4. Connect the HDDs to mainboard with gray cable. The connector outside the mainboard is for HDD.



Before installing the Hard Disk Drives, please read the jumper setting information on the label. If the jumper is not set properly, the system will be disordered.



5. Make sure that the HDDs are set to "Master" & "Slave" properly and cover the top.



- * Check if HDD has no problem after HDD installation because record function may not work well due to HDD problem.
- * It may reboot automatically when HDD has problems or it doesn't detect HDD.
- * Contact your local distributor and exchange with new one when you find your HDD has a problem.

TROUBLE SHOOTING

In the event of a product malfunction, please check the list below for a possible solution before requesting service.

Problem		Explanation / Solution
Power	No power	 Check that the power plug is connected to a wall outlet and a SMPS
Video	No Video or the Video is back screen	 ✓ Check the video input / output connections on the product rear panel ✓ Check the camera / the camera video/power cable connections ✓ Check if Camera status in menu is SHOW → Refer to Page 18
	Not display camera name	✓ Camera name is shown only in full screen mode.
Audio	No Audio but Video is O.K during monitoring / No Audio but Video is O.K during playback	 ✓ Check the audio input / output connections on the product rear panel ✓ Audio works only in full screen mode
Playback	Can't stop recording by remote controller	✓ Check RECORD CONTINUOUS of REC OPTION of MENU is OFF
	Can't find previous recording data	✓ The product operates automatically OVERWRITE function. It deletes previous recording data to overwrite when HDD is full.
Backup	Not compatible with USB memory stick	✓ Please check if USB memory stick has protection(Password) function. USB memory stick should not have protection function.
Network	Can't connect by network	 ✓ Check if network of menu is setting correctly ✓ Check if your internet line is available. Please ask your service provider to check internet line

If the problem you are experiencing persists or is not mentioned above, please contact service center or your local distributor.